


SERVICE PARTS INFORMATION FOR COMMERCIAL DOOR OPERATOR MODEL GD-03/H



IN THE EVENT OF POWER FAILURE
 UNSCREW EYEBOLT 2 OR 3 TURNS
 (DO NOT REMOVE) AND SLIDE IN
 DIRECTION OF ARROW (TOWARDS FLOOR)
 AND RELEASE PUSHARM FROM TROLLEY



PART NO.	DESCRIPTION	NO OFF
32	CENTRE SUPPORT BRACKET	1
31	DRIVE UNIT COVER	1
30	TRANSMITTER	1
29	RADIO RECEIVER	1
28	CONTROL MODULE	1
27	POTENTIOMETER	1
26	GUIDE ROD	1
25	ACTUATOR GD-81/H ONLY	1
24	DOOR BRACKET (PANELIFT)	1
23	PUSH ARM	1
22	TROLLEY	1
21	DRIVE NUT	2
20	END BEARING	1
19	FOLLOWER GUIDE	2
18	THRUST BEARING	1
17	COLLAR	2
16	BEARING HOUSING	1
15	BEARING	1
14	DRIVE PULLEY 4 1/2 x 1/2 x 1A	1
13	REED SWITCH	2
12	WORM DRIVE SPECIFY LENGTH	1
11	REED SWITCH CHANNEL	1
10	DRIVE CHANNEL	1
9	END MOUNTING BRACKETS	2
8	MOTOR VIBRATION RUBBER	2
7	BASE PLATE	1
6	SPRING & STRUT	2
5	REAR MOTOR BRACKET	1
4	TENSION BRACKET	1
3	V-BELT A-18	1
2	MOTOR PULLEY 1 1/2 x 1/2 x 1A	1
1	MOTOR 240v 50hz 3a 900rpm	1